



1. SWI-ST tube and SWI-EX if depth exceeds 120mm.
2. Fixing installed through spacer into substrate.
3. Neoprene washer.
4. Fixing by Others (site-specific pull-out tests).

Dependant on depth required multiple Ex tubes may be used. Ensure it is installed the correct way round as per tapered part. For ease of installation, they can be secured using insulation tape.

DRAWING TITLE: SWIFIX FIXING DETAIL - SWI-ST -EX



Protecting Your Investment

DRAWING No: EP - 002

DATE: 26-08-2022

SCALE: NTS

REFERENCES:

www.swifix.co.uk, info@swifix.co.uk