



SWIFIX Fixings installation guidelines SWI/TR



These guidelines are for the Fitting of Tetra three point safety system and catenary wires through external wall insulation (EWI) or solid wall insulation (SWI) systems using Swifix fixings.

It is important that our installation guidelines are adhered to since the EWI/SWI system must not be compromised.

If you require any assistance, please contact us on 01884 560477 or email info@swifix.co.uk

All Swifix fixings are easy to fix following our step by step instructions. All fixings are manufactured from high quality plastics, are robust and have been fully tested for strength, compression and load.

Installation guidelines for eyebolt Installation



1 Drill a 16 -18mm hole through the render and insulation until the original substrate is reached.



2 Insert tube, or measure depth of hole from finished render back to the original substrate, adding an allowance of 3-4mm to allow the neoprene washer to compress and provide a seal when installed.




3 Cut tube to length using pipe cuner or hacksaw.




4 Place the neoprene washer onto tube and insert tube into wall.



5 Drill the correct size hole and depth for the throughbolt through the tube, and clear debris from hole.



6 Insert throughbolt, once at the correct depth, tighten nut.



7 Attach eyelet.



SWIFIX Ltd

Email info@swifix.co.uk
Web www.swifix.co.uk
Tel 01884 560477

Scan QR code for installation videos



#FollowTheBear

